# **REMOVIL Liquid**

Alkaline detergent with high causticity

## ---> DESCRIPTION

**Removil Liquid** is a liquid alkaline formulation with high causticity, suitable for the cleaning of closed lines in all sectors of the alimentary industry and beverage bottling.

**Removil Liquid** is able to easily remove all residues of animal and vegetable fat, proteins, oil and organic contaminations in general from the treated surfaces.

**Removil Liquid** contains components with a wetting action, which facilitate the washing action of the alkaline part and enable to wash with working concentrations lower than with the utilization of sodium hydroxide alone. The controllers of the water hardness (sequestering) enable to eliminate the negative effects of waters with average hardness.

In order to optimize the results of washing cycles, in some sectors we suggest a subsequent descaling acid phase, with a periodicity to be estimated.

# TECHNICAL CHARACTERISTICS

Physical appearance: light brown liquid pH (3% solution): > 12 pH: > 12 Relative density at 20°C: 1,50 ± 0,05 Conductivity 1% sol. at 25°C: 22 mS/cm

The above indicated chemical-physical data represent the typical product's characteristics drawn from the analysis carried out on the product. These values are not a specification.

### → INSTRUCTIONS FOR USE\*

Use **Removil Liquid** at concentrations from 0,8 to 3,0%, according to the kind and degree of the contamination. Even if, like all caustic products, **Removil Liquid** achieves its maximum activity at temperatures above 50°C, the formulation has shown excellent detergent and detartarising capacity even at room temperature, especially in the oenological sector. Final rinsing with drinking water till any possible residue of detergent is completely eliminated.

### → FIELDS OF APPLICATION

For the alkaline washing of closed circuits, tanks and pipes, CIP plants, heat exchangers (pasteurizers, skimmers, evaporators). For the alkaline washing in washing tunnels and/or by immersion for moulds, trays and different containers. For the washing of fillers.



# REMOVIL Liquid

# --> COMPATIBILITY OF THE FORMULATION

**Removil Liquid** is compatible with most material normally present in food industries, if used according to the producer's indications. Do not use on aluminium, copper, zinc-plated iron and surfaces treated with phenolic resins. In case of doubt, carry out a test on the single material before using the product.

# -> PRECAUTIONS FOR HANDLING AND STORAGE

Store the formulation far from extreme temperatures. Sensitive to low temperatures. Consult the Material Safety Data Sheet.

### → TITRATION METHOD

Sample: 50 mL of washing solution. Indicator: phenolphthalein. Titrating agent: hydrochloric acid (HCl) 1N.

% (v/v) **Removil Liquid** = mL titrating agent x 0,12 % (w/w) **Removil Liquid** = mL titrating agent x 0,18

### --> PACKAGING

15 kg net drums.25 kg net drums.300 kg net drums.1450 kg net IBC.

\* The indications have been established for general use conditions. For conditions differing from the norm, for example depending on the particular water hardness, the working method or cleaning problems, please consult us; our technical service will be pleased to advise you and to cooperate with you.

